

Projecting from Laptop

1. **Turn data projector on** with remote control. Please allow 45 seconds for projector to turn on and warm-up.
2. **Select Computer (RGB1)** on data projector remote control.
3. **Connect the 15 pin SVGA cable to your laptop** (port is normally blue).
4. **Connect network cable** if you need Internet access. This looks like a large phone jack.
5. **Turn your laptop on.**
6. **For audio**, plug the black 3.5mm plug into the headphone jack of your laptop.
7. **Turn amplifier power on, select DVD.**
8. **Adjust volume on the amplifier.**

***Note: If your laptop does NOT display correctly on the projector, try changing your screen resolution (right click on desktop and select properties) to “1024 x 768” or “800 x 600” pixels and medium color (16 bit). A “restart” of your laptop may be necessary for the change to take effect.**

****Note: If your laptop does not display on the projector, you may have to use the appropriate function key to enable your laptop’s video output port.**

Projecting from VCR/DVD Combo

1. **Turn data projector on** with remote control. Please allow 45 seconds for projector to turn on and warm-up.
2. **Select Video (VIDEO)** on data projector remote control.
3. **Turn VCR/DVD Combo unit on.**
4. **Insert media and select VCR or DVD on combo unit.**
5. **Turn amplifier power on, select Video 1.**
6. **Adjust volume on the amplifier.**

Note: DVD player can also play audio and MP3 CD’s.

FOR AV ASSISTANCE:

**AT LEMOORE, CALL
3421 or 3408, OR PAGER 3424.**